
Installation Manual USB-IrDA Adapter

USB-IrDA Adapter

**Windows XP/2000/ME/98SE
InstallShield Installation and Removal**

Release 1.26


This document provides instructions to install and remove the USB-IrDA Adapter on Windows XP/2000/ME/98SE.

1 USB-IRDA ADAPTER DRIVER INSTALLATION FOR WINDOWS 2000/ME/98SE


Following are the instructions to properly install the USB-IrDA Adapter under Windows 2000, Windows ME, and Windows 98SE.

Important: If you have a previous version of the driver loaded, please keep the USB-IrDA Adapter plugged into the computer until prompted to remove it. If you do not have a previous version of the driver loaded, do not plug the USB-IrDA Adapter into the computer until prompted.


1. Insert the disk that contains the driver files. Double-click on the "setup.exe" file on the disk. Click on **Next** to continue.




2. The Installer will copy files required for installation and removal to this default directory. To continue, click the **Next** button.



3. To complete the installation, plug the USB-IrDA Adapter into the USB jack at this time. Or, if the USB-IrDA Adapter is already plugged in, remove it then re-insert it into the USB jack. Click on **Finish** to continue.



4. Windows will now detect the USB-IrDA Adapter. On some operating systems, you may be prompted to restart your computer. If so, click "Yes" to continue.




5. Installation is complete.

2 USB-IRDA ADAPTER DRIVER INSTALLATION FOR WINDOWS XP


Following are the instructions to properly install the USB-IrDA Adapter under Windows XP.

Important: If you have a previous version of the driver loaded, please keep the USB-IrDA Adapter plugged into the computer until prompted to remove it. If you do not have a previous version of the driver loaded, do not plug the USB-IrDA Adapter into the computer until prompted.

1. Insert the disk that contains the driver files. Double-click on the "setup.exe" file on the disk. After the splash screen, the following screen will appear. Click on **Next** to continue.



2. The Installer will copy files required for installation and removal to this default directory. To continue, click the **Next** button.



3. Click on **Continue Anyway** to continue



4. Insert the USB-IrDA Adapter into the USB Jack and click on **Finish**.



- WinXP will detect the USB-IrDA Adapter. Select **Install the software automatically (Recommended)** and click on **Next**.



- WinXP will detect the updated drivers. Click on **Continue Anyway** to continue.



- Click on **Finish** to complete the installation.




3 USB-IRDA ADAPTER DRIVER REMOVAL FOR WINDOWS XP/2000/ME/98SE


Following are the instructions to properly uninstall the USB-IrDA Adapter under Windows XP, Windows 2000, Windows ME, and Windows 98SE.

Important: Please keep the USB-IrDA Adapter plugged into the computer until prompted to remove it.


1. Open the **Control Panel** and select **Add/Remove Programs**.



2. Select **USB-IrDA Adapter** from the list. Click on the **Add/Remove** button to begin the uninstall process.



3. To continue, click the **Yes** button to uninstall the USB-IrDA Adapter.



4. To complete the removal process, click the **Finish** button. Unplug the USB-IrDA Adapter from your USB jack.

